TOP AND CONSOLE PARTS

27" ELECTRIC DRYER

For Model: WED9151YW0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: WED9151YW0
(White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10385092	Use & Care Guide
	W10386307	Tech Sheet
	W10385103	Installation Guide
2	W10336080	Top
3	W10251442	Harness, Main
4	W10380697	Panel, Console
6	8565237	Bracket, Console
8	W10212742	Window, LED
9	W10370331	Knob Assembly
10	W10387226	Assembly, User Interface
11	3390647	Screw, 8−18 x 1/2
12	W10266747	Chanel, Water
13	W10117943	Badge, Assembly
14	8572039	Seal, UI

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: WED9151YW0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: WED9151YW0
(White)

Illus. No.	Part No.	DESCRIPTION
1	W10286180	Cover, Terminal Block
2	3390814	Screw, 8−18 x 3/8
3	8519459	Clip, Toe Panel
4	3397659	Block, Terminal
5	W10246525	Switch, Broken Belt
6	8533971	Screw, 8−18 x 5/16
7	8565054	Panel, Side (L.H.)
8	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor
10	3387374	Spring, Idler
11	3389420	Retainer, Idler
12	49252	Plug, Multivent
13	3388672	Pulley Assembly
14	279318	Terminal, Brass & Tinned (Includes Illus. 33)
15	8565122	Strike, Door
16	8563727	Bracket, Control
17	3357011	Screw,10−16 x 1/2
18	W10121334	Washer, Thrust
19	W10318609	Switch, Assembly Door
20	690997	Tri Ring
21	8066115	Cover, Plate
22	8580015	Ramp, Door
23	W10085210	Label, Hinge Hole Cover Front Panel
24	8565048	Panel, Side (R.H.)
25	8565059	Panel, Rear
26	343641	Screw, 10−16 x 1/2
27	8538263	Motor, Assembly 60 HZ.
28	3393008	Screw, 10−16 x 1/2
29	8578220	Pulley 60 HZ.
30	3387610	Belt, Drive
32	W10242878	Bracket, Motor
33	279393	Terminal Block Screw Kit (For Terminal Block)
34	49026	4" − 90° Elbow
35	8533974	Screw, Ground
36	8563747	Exhaust Pipe & Bracket
37	8563750	Exhaust Pipe (Short)
38	8563749	Exhaust Pipe (Long)
39	3388674	Idler Bracket
40	8540621	Toe Panel
41	W10286016	Control Board
42	8565046	Base, Cabinet
43	3390647	Screw, 8−18 x 1/2
44	3387242	Seal, Front Panel
45	8580257	Front Panel (Includes Illus. 44)

Optional Parts Not Included

Dryer Exhaust Kit (For Side & Bottom Venting)

46	W10331132	Midnight Grey

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: WED9151YW0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: WED9151YW0
(White)

Illus. No.	Part No.	DESCRIPTION
1	W10359271	Shaft, R.H. Thread
2	3390647	Screw, 8−18 x 1/2
3	W10153413	Door, Lint Screen
4	8066099	Bracket, Heater Box
5	697354	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	697814	Seal, Drum Front
8	3934666	Nut,3/8 x 16(R.H.)
9	697770	Seal, Cover Plate
10	3402841	Lens, Drum Light
11	693995	Screw, 8−18 x 3/8
12	8572105	Clip, Exhaust
13	8533971	Screw,8−18 x 5/16
14	8544771	Heater Element
15	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)
16	W10001120	Nut,3/8 x 16(L.H.)
17	W10080170	Bulkhead, Rear
18	3387459	Washer, Support
19	W10359272	Shaft, L.H. Thread
20	690997	Ring, Tri
21	W10314171	Roller, Support
22	8563728	Exhaust Pipe
23	W10153423	Housing, Outlet
24	W10153412	Grille, Outlet
25	W10153420	Complete Drum Assembly
26	W10219342	Screw, 8−16 x 3/4
27	W10166807	Seal, Drum
28	695240	Screw, 8−18 x 1/2
29	8544776	Flange, Heater Box
30	8565061	Bulkhead, Front
31	3387230	Screw, 10−16x13/16
32	489463	Screw, 8−18 x 5/8
33	3406124	Bulb, Light
34	3387223	Electrode, Sensor
35	8578825	Bracket, Drum Light
36	W10214261	Socket Assembly
37	697772	Wheel, Blower
38	3392519	Thermal Fuse (91°C)
39	3394986	Spring, Lint Screen Door
40	W10345456	Clip, Spring
41	W10049370	Lint, Screen
42	8577274	Thermistor
43	3390647	Screw, 8−15 x 1/2
44	8544362	Housing, Blower
45	8066168	Lint Duct Assembly
46	8544769	Housing, Slot Heater Box
47	8318314	Thermal Cut−Off (Includes Illus. 48)
48	3391914	Thermostat 295°F (146°C)
49	W10153409	Baffle, Drum
50	W10110975	Harness, Moisture Sensor
51	3406653	Harness, Sensor
52	8544770	Housing, Tab Heater Box
53	W10153414	Housing, Outlet

DOOR PARTS

For Model: WED9151YW0
(White)



Illus. No.	Part No.	DESCRIPTION
1	W10256915	Label, Hinge Hole Cover
2	8578887	Door, Hinge Assembly
3	W10215741	Screen, Door (Not Serviceable Sperately, Order Item. 19)
4	8534044	Screw,8−18 x 1/2
5	W10371560	Door, Intermediate Stationary
6	W10371558	Door Trim Outer Ring
7	W10163915	Door Seal
8	W10159996	Screw
9	W10215766	Door Trim, Hinge Cover
10	W10363674	Door Assembly
11	355515	Screw, 8−18 x 11/16
12	3393258	Screw, 10−16 x 1/2
13	W10286878	Window
14	690081	Door Catch Assembly
15	8579663	Seal, Window
16	8519354	Retainer (Lower)
17	8565087	Nut, 1/4−28
18	8519356	Retainer (Upper)
19	W10371557	Door Assembly Outer
20		Door Trim Inner Ring (Not Serviceable Seperately, Order Item. 19)
21	W10215762	Door Intermediate Rotational
22	W10270216	Door Assembly Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: WED9151YW0
(White)

Illus. No.	Part No.	DESCRIPTION

PAINT, TOUCH−UP (1/2oz.)

72017	White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (uncut)

ACCESSORY PARTS

8529894	Hold Down Kit
8522199	Kit, Dryer Vent Testing
80047	Kit, Dryer Repair
8572546	Kit, Stacking

ACCESSORY PARTS

The following power cord can be ordered.
Important: Check local wiring code requirements to see if one of these meets your needs.

PT220L	4’ 30 Amp 3 Wire Dryer Cord
PT400L	4’ 30 Amp 4 Wire Dryer Cord
PT600L	6’ 30 Amp 4 Wire Dryer Cord